

Model 994 Intelligent Integrated Instrument System

Leading Universal Process Control Instrumentation Solutions

QUICK SETUP INSTALLATION

- 1 Connect input or output into the desired instrument port as shown.
- 2 Insert power plug into the 12-24V jack, or connect alternate 12-24V power to the screw terminal plug, followed by installing the plug into the corresponding jack as shown.
- 3 Plug the D9 part of a (C75100AA) RS-232 cable into a computer serial port. Insert the plug on the other end of the cable into the 994 SIO-I jack as shown.
- 4 Plug one end of a (C75102AD) cable into the SIO-O jack, followed by plugging the other end of the cable into the SIO-I jack of another Florite unit as shown.
- 5 If your unit is installed with the WAN modem option then install the (C75106AG) cable (RJ-11) into the corresponding jack and the other end of the cable into a standard telephone jack as shown.
- 6 If your unit is installed with the RS-485 option then use a (C75103ZZ) cable to connect the **red wire** to signal A and the **white wire** to signal B, then insert the cable plug into the LAN jack as shown.

Alternatively, connect the A and B network wires into the screw terminal plug, followed by installing the plug into the corresponding jack as shown.

